



AGRICULTURAL MACHINERY SINCE 1920



## ***BRACCI DECESPUGLIATORI***

*Bush cutter machine*

*Debroussailleuse*






*Böschungsmäher*

*Brazo Deshojador*



# BRF






BRF

MOD	A mm.	B mm.	C mm.	D mm.	E mm.	F mm.	G mm.		 Kg	 KW CV	 Kg	
BRF/160	1700	1900	1100	2300	1100	1350	<b>500</b>	28	230	15 20	600	
BRF/250	2500	2400	2000	2800	1600	1700	<b>600</b>	28	260	18 25	700	
BRF/300	3000	2900	2500	3000	1800	1900	<b>800</b>	40	300	22 30	800	
BRF/350	3500	3400	3000	3500	2000	2100	<b>800</b>	40	350	26 35	900	



# BRV






BRV

MOD	A mm.	B mm.	C mm.	D mm.	E mm.	F mm.	G mm.		 Kg	 KW CV	 Kg	
BRV/400	4200	3400	3300	4800	2600	2300	<b>1000</b>	36	530	37 50	2100	
BRV/450	4700	3900	3500	5000	3100	2500	<b>1000</b>	36	570	44 60	2200	



# BRC






BRC

MOD	A mm.	B mm.	C mm.	D mm.	E mm.	F mm.	G mm.		 Kg	 KW CV	 Kg	
BRC/450	4500	3800	3500	3900	2400	2400	<b>1000</b>	32+16	820	44 60	2500	
BRC/485	4850	4150	3850	4250	2500	2450	<b>1000</b>	32+16	850	51 70	2800	
BRC/530	5300	4600	4300	4700	2650	2600	<b>1000</b>	32+16	870	59 80	3200	



# BRL


BRL





MOD	A mm.	B mm.	C mm.	D mm.	E mm.	F mm.	G mm.		 Kg	 KW CV	 Kg	
BRL/500	5100	4500	4200	4700	2400	3000	<b>1000</b>	32+16	990	59 80	3700	
BRL/600	6200	5300	5200	5700	2550	3900	<b>1200</b>	40+20	1060	66 90	4300	



**BRT**

**BRT TELESCOPICO**  
**BRT TELESCOPIC BUSH CUTTER MACHINE**  
**BRAS EFFEUILLEUR TELESCOPIQUE BRT**  
**TELESKOPBÖSCHUNGSMÄHER BRT**  
**BRAZO DESHOJADOR TELESCOPICO BRT**



MOD	A mm.	B mm.	C mm.	D mm.	E mm.	F mm.	G mm.		 Kg	 KW CV	 Kg
BRT/580	5800	5000	4800	5400	2450	3700	<b>1200</b>	40+20	1120	66 90	4200
BRT/660	6600	5900	5700	6600	2550	4100	<b>1200</b>	40+20	1220	73 100	5000



**Testa con trasmissione a cinghie**  
 Head With Belt Transmission  
 Tête Avec Transmission Par Courroies  
 Kopf Mit Riemenantrieb  
 Cabeza Con Transmisión Con Correa



**Barre di taglio falcianti per bracci decespugliatori**  
 Shred cutting bar for bush cutter machine  
 Barre de coupe fauchant pour bras effeuilleurs.  
 Stange für Böschungsmäher  
 Barra para brazo



**Testate per escavatori**  
 Heads for boom machines  
 Tête pour excavateurs  
 Kopf für Bagger  
 Testada para escavadora



**Barre di taglio a dischi per bracci decespugliatori**  
 Disc cutting bar for bush cutter machines  
 Barre de coupe avec disques pour bras effeuilleurs  
 Stange mit Scheiben für Böschungsmäher  
 Barra con discos para brazo

**RINIERI S.r.l.**

**47121 FORLÌ (ITALY) - Viale dell'Appennino, 606/B**  
**Tel. 0543 86066 - Fax 0543 83418**  
**rinieri@rinieri.com - www.rinieri.com**

